

# **VERY IMPORTANT! PLEASE READ!**

## **M80 Subwoofer System Supplement**

In order to prevent damage to your gas tank or fuel system, it is **IMPERATIVE** that when drilling into the vehicle that you drill **NO FURTHER** than  $\frac{1}{4}$ " through the sheet metal!

To ensure that you drill no further than the recommended  $\frac{1}{4}$ ", we suggest using something (a piece of wood, plastic, etc) that will not allow your drill bit to penetrate the metal more than this distance.

**In short, measure the distance that your drill bit extends from the head of the drill. If it is 3", you'll want to use a piece of wood that is 2.75" thick, therefore not allowing the bit to penetrate any deeper than  $\frac{1}{4}$ " into the Z3 chassis.**